


CAN 1380

- Ⓒ **Parts List - Model 633134x54A**
- Ⓕ **Liste de pièces - Modèle 633134x54A**
- Ⓓ **Teileliste - Modell 633134x54A**
- Ⓘ **Elenco pezzi - Modello 633134x54A**
- Ⓝ **Deleliste - Modell 633134x54A**
- Ⓢ **Reservdelista - Modell 633134x54A**
- ⓈⒻ **Varaosaluettelo - Malli 633134x54A**
- Ⓔ **Lista de partes - Modelo 633134x54A**

# MODEL 633134x54A

# REPAIR PARTS ENGINE




Key No.	Part No.	Description
1	761332	CORD, STARTER
2	-----	ENGINE
3	2x97	BOLT, CARRIAGE 5/16-18
5	28x76	RETAINER, PUSH
6	710026	NUT, HEX 5/16-18
8	1501109	PULLEY, ENGINE
10	710247	WASHER
12	71063	WASHER .38ID
14	71015	SCREW, 3/8-24X1.00
16	585416	BELT, V 4L 38.1MF16" 5-10
18	579932	BELT, V 3L 33.13LG
20	1501201	GUIDE, BELT
22	71060	WASHER .31X.58X.08
24	710097	SCREW, 5/16-24X .75
25	-----	FRAME ASSEMBLY
25-1	1501062E245	PLATE, ENGINE MOUNT
25-2	310169	SCREW, TAP 1/4-20 X .63
25-3	780055	SCREW, TAP 5/16-18 X .50
25-4	1501049E245	FRAME, MOTOR BOX
—	F-021049L	OWNER'S MANUAL

ENG1C

# MODEL 633134x54A

# REPAIR PARTS GEAR CASE




GEAR106A

No.	Part No.	Description	Key No.	Part No.	Description
300	896	CASE, GEAR, RH	322	48275	COLLAR, THRUST
301	895	CASE, GEAR, LH	323	50684	PIN, SPRING
303	910828	SCREW, 1/4-20X.75	324	48275	WASHER, FLAT
304	71100	NUT, 1/4-20	326	50795	BRNG, FL
305	1441	SCREW, 5/16-24X1.75	327	53732	SEAL, OIL
306	53749	SCREW, 3/8-16X.50	330	53731	BEARING
310	780151	SEAL, OIL	340	1501148E717	IMPELLER
311	53743	BEARING, FL	350	1442 YZ	LF BRACE, GEAR BOX
312	53748	WASHER, FLAT	352	71100	NUT, 5/16-24
313	760411	SHAFT, AUGER OUTPUT	355	302636	SCREW 5/16-18X1.25
314	897	GASKET, GEAR BOX	356	71071	WASHER
315	53730	WORM GEAR	357	71060	WASHER
316	73905	KEY, WOODRUFF #61	358	71037	NUT 5/16-18
320	53737	BRNG, FL	—	333431	10oz TUBE LUBRIPLATE
321	583126	SHAFT, AUGER INPUT			

# MODEL 633134x54A


# REPAIR PARTS FRAME



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
90	1501055E717	COVER, BOTTOM
91	310169	SCREW
103	1501369 YZ	IDLER, AUGER
105	711682	PIN, HAIR
106	761761	PIN, KLIK
107	165x159	SPRING, TENSION
108	761675 YZ	ATTACH, SPRING
110	585781	BOLT, CARR.
111	711617	WASHER, FLAT
112	1501112 YZ	BRACKET, IDLER
114	1501065	BUSHING, IDLER
116	710097	SCREW
118	71060	WASHER, SPLIT
122	780055	SCREW, TAP
145	53704	SPRING, IDLER
148	50793	PULLEY, IDLER
149	590	NUT, JAM
160	1501171	COVER, BELT
162	310169	SCREW, TAP
166	71067	WASHER, FLAT
168	1501200	SPACER, AUGER
169	761167	LID, TOOL BOX
170	761187	PAD, FOAM

# MODEL 633134x54A


# REPAIR PARTS DRIVE



Key No.	Part No.	Description
200	1501092 YZ	LF AXLE, SWING PLATE YZ
201	579851	CHAIN, ROLLER #42x19.00
203	334163	BEARING AND RETAINER, ASSY
204	579858	WASHER
206	780055	SCREW, TAP 5/16-18x0.5
207	1501100	ASSY, HEX SHAFT
208	579868	CHAIN, ROLLER #36x18.00 LG
210	337029	BEARING, TRUNION CLUTCH R
212	1501435	WHEEL, FRICTION DISC
213	1X38	SCREW, 1/4-20 x 0.63
215	303008	NUT, KEPS HEX 1/4-20
217	579859	RING, RETEXT
218	579858	WASHER
220	334163	BEARING AND RETAINER, ASSY
221	780055	SCREW, TAP 5/16-18 x .5
223	1501115	ASSY, FRICTION PULLY
225	1501057 YZ	LF PLATE, SWINGING YZ
226	1501158	SPACER, FRICTION PULLEY
227	15X114	NUT, FLANGE LOCK 3/8-24
229	11X30	RETAINER, RING
230	1501107 YZ	LF ASSY, SPRING LINK YZ
232	11X30	RETAINER, RING
234	165X112	SPRING, EXTENSION
236	1501090	WLD, INTERMED SPROCKET 33T/7
238	71074	WASHER, FLAT

# MODEL 633134x54A

# REPAIR PARTS AUGER HOUSING




AUG107



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
480	583146	PULLEY
482	2001022	KEY, SQUARE
484	15X112	NUT, 1/4-20
485	1501158	SPACER, FRICTION PULLEY
490	582957 YZ	RETAINER, BALL BRNG
491	43846	BEARING, BALL
493	001X92	BOLT, HEX - 0.31-18X0.50
499	710026	NUT, 5/16-18 HEXWDFLLK
500	1501162E245	HOUSING, ASSY
509	760040	PLUG, CHRISTMAS TREE
510	760668E717	BLADE, SCRAPER
511	340720	BOLT, CARRIAGE
514	710026	NUT
520	760317E717	AUGER, ASSY, LH
521	760307E717	AUGER, ASSY, RH
522	578647	BOLT
524	71391	NUT, 5/16-18
525	53757	BEARING, FLANGE
527	70984	SCREW, 5/16-18X .75
536	340720	BOLT
540	762377E717	SKID, HEIGHT ADJUST
541	340720	BOLT, 5/16-18 X .75
544	710026	NUT, 5/16-18 REGHEX

# MODEL 633134x54A


# REPAIR PARTS HANDLE



Key No.	Part No.	Description
720	1501378E717	ASSY, HANDLE
724	7288	SCREW
725	71072	WASHER, FLAT
726	71062	WASHER
727	71044	NUT
728	7289	STOP, PLASTIC
729	337399	GRIP, HANDLE
739	4049	BUMPER
740	1501452	CABLE, CLUTCH
741	1501451	CABLE, CLUTCH
743	313441	BRKT, CABLE ADJ
744	1673	SPRING, CLUTCH
745	780029	NUT, HEX
750	1501449E717	HANDLE, LOWER
751	70984	SCREW
752	71060	WASHER, SPTLK
758	001798	BOLT, HEX
759	579860	SPOOL, CABLE
760	1501059 YZ	BRKT, SPOOL
762	1501122	CABLE, DRIVE
765	308146	BOOT, CABLE
770	1501375 YZ	BRACKET, SHIFT
771	71007	SCREW
772	50786	SPRING
773	71072	WASHER, FLAT
774	71046	NUT, HEX
785	71045	NUT, HEX
787	306689	KNOB, SHIFT
790	578926	ROD, ASSY LH
791	578924	ROD, ASSY RH
795	579002	BRACKET, CAM
796	002x53	SCREW
798	71038	NUT, NYLOCK
799	8417	CAM LOCK
800	584673	PIN, SPRING PIVOT
801	73664	NUT, PUSH ON
802	71081	PIN, COTTER
803	71071	FLATWASHER
804	1501453	ROD, SPEED CTRL
805	71042	NUT, HEX
808	584593 YZ	NUT, TRUNNION
809	71071	WASHER
810	71081	PIN, COTTER
811	579944	BEARING, FL
812	1501110 YZ	ROD, YOKE
813	11X30	RETAINER, RING


# MODEL 633134x54A

# REPAIR PARTS CONTROL PANEL ASSEMBLY



319052


Key No.	Part No.	Description	
730	1501357E717	CLUTCH HANDLE LH	<i>GAUCHE</i>
731	1501358E717	CLUTCH HANDLE RH	<i>GAUCHE</i>
760	1501327	PANEL, CONTROL	
761	316042	SCREW, 10 X .62	
765	578866E717	BRACKET, PANEL	
766	302900	SCREW, 5/16-18 X 1.75	
767	71060	WASHER	
768	71037	NUT, 5/16-18	
792	905531	BOLT, 1/4-20 X .50	
794	908913	NUT, 1/4-20	



Key No.	Part No.	Description
621	762343	LIGHT
622	1501455	HARNESS, WIRE
625	57444	TIE, CABLE
626	578921	BRACKET
627	901696	SCREW #8 X .50
628	901736	WASHER, FLAT
629	1501401	COVER
630	1501402	COVER
631	1501330	FRAME
632	028x79	NUT, PUSH

# MODEL 633134x54A


# REPAIR PARTS DISCHARGE CHUTE



<b>Key No.</b>	<b>Part No.</b>	<b>Description</b>
580	761168E717	CHUTE, UPPER W/REMOTE
582	578088	SCREW, 5/16-18 X.75
584	71038	NUT
585	578088	SCREW, 5/16-18 X.75
586	6711	PLASTIC WASHER
587	71038	NUT
600	761329E717	CHUTE, LOWER WITH GUARD
601	2x100	BOLT
602	71071	WASHER, FLAT
603	71038	NUT
604	762322	FLAP
605	760987	RIVET
606	585214 YZ	CHUTE COLLAR
607	340714	BOLT
609	15X145	NUT
610	337227	RETAINER, RING INNER
611	1501282	RETAINER, RING OUTER

# MODEL 633134x54A


# REPAIR PARTS CHUTE ROD






# MODEL 633134x54A

# REPAIR PARTS REMOTE CHUTE CONTROL



Key No.	Part No.	Description	Key No.	Part No.	Description
965	318468	SPRING, TENSION RETURN	973	95105	TRIM
966	711666	WASHER, FLAT	974	760113	TIE, CABLE
967	310088	BOLT, 5/16-18	975	1501393	CABLE, CHUTE CONTROL
968	73787	WASHER, FLAT	981	780220	WIRE FORM
969	302635	NUT, 1/4-20	990	760858	SCREW, 3/8-16X1.75
970	313676	SCREW, 5/16-18 X .75	994	71045	NUT, 3/8-16 HEX JAM
971	306447 YZ	BRACKET, CABLE CHUTE	995	306689	HANDLE, 3/8-16 MOLDED
972	71391	NUT, 5/16-18			



WHL102B

Key No.	Part No.	Description	
	650	1501284	SHAFT, AXLE
	652	1501089	SPRKT & HUB
	653	01x193	BOLT, HEX 1/4-20X1.75
	654	15X145	NUT, 1/4-20 HEX NYLOCK
	655	1501114	RETAINER, BEARING
	671	712120	WASHER, FLAT
	673	1501138	BUSHING, WHEEL
	675	580362	TIRE & RIM -RIGHT
	676	577015	SCREW, 1/4-20X1.75 HH
	677	15x145	NUT, 1/4-20 HEX NYLOCK
	678	239	RING, RET
	680	580362	TIRE & RIM -LEFT
	681	1501032	DISC, WHEEL
	682	2001066	SCREW
	683	1501031	HUB, WHEEL LOCK
	684	164X34	SPRING, COMPRESSION
	685	1501033	PIN, LOCK
	686	1501034	KNOB
	687	032X79	PIN
	688	73839	SCREW
	689	15X145	NUT